



Tow-Trust Towbars

Important:

Please Read General Notes (overleaf) Before Fitting:

Issue 3

Type TP424 Peugeot 806 & Expert Van 95 > Citroen Synergie 95 > & Dispatch Van 96 > Fiat Ulysses 95 > & Scudo Van 96 >

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	E	2	M16x50 Bolts Nuts & Washers
B	1	Left Hand Side Arm	E1	2	M16x40
C	1	Right Hand Side Arm	F	9	M10x35 Bolts 4 Nuts 9Washers
D	1	Extension Bar	G	6	10mm Caged Nuts
			H	8	10 x 25 Flat Washers
			J	1	Special Bolt

1. Lower the spare wheel.
2. Locate the six existing towbar mounting points (these are covered with tape) insert item G through the square holes and pull back into place.
3. Using item F with item H loosely bolt item A into place.
4. Using item F with item H loosely bolt item B to item A and to the forward mounting point using item J.
5. Using item F loosely bolt item C to item A and to the remaining forward mounting point.
6. Cut a slot 30mm up x 45mm wide from the lower edge of the plastic bumper (see sketch).
7. Using item E1 bolt item D to item A.
8. Using item E bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
9. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
10. Replace the spare wheel.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

